# Paura & Associates Inc. Structural Engineering for the Building Envelope Industry

## Amico Mesh Panel Design Guide


All content relates exclusively to AMICO products and cannot transfer to other meshes

Date: 3/23/2021 Client: AMICO

# Paura & Associates Inc. Structural Engineering for the Building Envelope Industry

### Mesh Panel Wind Load Charts

Date: 3/23/2021 Client: AMICO




APEX01 Landscape Style:


- -8" LWD x 3.5" SWD
- -46% open area

To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges






APEX01 Landscape Style:


- -8" LWD x 3.5" SWD
- -46% open area

#### Design Criteria:

- Min. of L/60 or 1" deflection criteria where L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable






#### APEX01 Portrait Style:


- -8" LWD x 3.05" SWD
- -40% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges






#### APEX02:


- -8" LWD x 3.5" SWD
- -46% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges






#### APEX02:


- -8" LWD x 3.5" SWD
- -46% open area


#### Design Criteria:

- Min. of L/60 or 1" deflection criteria where L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges



- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable







- -6" LWD x 2.5" SWD
- -26% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges







- -6" LWD x 2.5" SWD
- -26% open area


#### Design Criteria:

- Min. of L/60 or 1" deflection criteria where L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges



- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable







- -6" LWD x 2.5" SWD
- -26% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -3003-H14 Allowable stress of 10.3ksi
- Assumed no cantilever at edges







- -6" LWD x 2.5" SWD
- -26% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges







- -6" LWD x 2.5" SWD
- -26% open area


#### Design Criteria:

- Min. of L/60 or 1" deflection criteria where L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges



- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable







- -6" LWD x 2.5" SWD
- -26% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -3003-H14 Allowable stress of 10.3ksi
- Assumed no cantilever at edges






#### Apex04:


- -3" LWD x 1.375" SWD
- -6.25% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges






#### Apex04:


- -3" LWD x 1.375" SWD
- -6.25% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -3003-H14 Allowable stress of 10.3ksi
- Assumed no cantilever at edges






#### Bilbao:


- -4" LWD x 1.5" SWD
- -18% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges






#### Bilbao:


- -4" LWD x 1.5" SWD
- -18% open area


#### Design Criteria:

- Min. of L/60 or 1" deflection criteria where L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges



- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable






#### Bilbao:


- -4" LWD x 1.5" SWD
- -18% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -3003-H14 Allowable stress of 10.3ksi
- Assumed no cantilever at edges






#### Sunshade:

- -1.2" LWD x 0.625" SWD
- -36% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -5005-H34 Allowable stress of 9.10ksi
- Assumed no cantilever at edges






#### Crescent:


- -4" LWD x 0.375" SWD
- -25% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges






#### Pisa:


- -4" LWD x 0.59" SWD
- -52% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges





#### Venetian:

- -5.33" LWD x 0.521" SWD
- -55% open area

#### To use wind chart:

- -Determine maximum wind load for project
- -Select appropriate wind load curve
- -If proposed LWD and SWD clip spacing falls below curve then proposed is acceptable

- Min. of L/60 or 1" deflection criteria where
   L is the largest clip spacing
- -5005-O Allowable stress of 5.27ksi
- Assumed no cantilever at edges

